

6.4
EMATIC
LLEL/SERIAL INTERFACE
DIE P/I TERMINAL

REF
396246



FIG 6.4
SCHEMATIC
PARALLEL/SERIAL INTERFACE
REMOTE R/T TERMINAL



FIG.6.5 SCHEMATIC
TELEPHONE LINE INTERFACE
REMOTE R/T TERMINAL



FIG.6.5 SCHEMATIC
TELEPHONE LINE INTERFACE
REMOTE R/T TERMINAL



FIG. 6.6
METER SCALING BOARD
REMOTE R/T TERMINAL

REF.
396301



FIG. 6.6
METER SCALING BOARD
REMOTE R/T TERMINAL

REF.
396301



FIG. 6.7
DIAGRAM, WIRING
ASTER CONTROL TERMINAL

REF.
589335
SHT 2 OF 2



SCHEMATIC FOR ASSY 707636-802,-803

FIG. 6.7
DIAGRAM, WIRING
MASTER CONTROL TERMINAL

REF.
589335
SHT 2 OF 2



FIG. 6.8
DATA CONVERTER
MASTER CONTROL TERMINAL

REF.
816739



FIG. 6.8
DATA CONVERTER
MASTER CONTROL TERMINAL



FIG. 6.9
TELEPHONE LINE INTERFACE
MASTER CONTROL TERMINAL

REF.
816740



FIG. 6.9
TELEPHONE LINE INTERFACE
MASTER CONTROL TERMINAL



FIG. 6.10
SCHEMATIC
DATA CONVERTER
MASTER CONTROL TERMINAL



FIG. 6.10
SCHEMATIC
DATA CONVERTER
MASTER CONTROL TERMINAL



FIG. 6.11
SCHEMATIC
TELEPHONE LINE INTERFACE
MASTER CONTROL TERMINAL

REF.
396244
6-12



FIG. 6.11
SCHEMATIC
TELEPHONE LINE INTERFACE
MASTER CONTROL TERMINAL

REF.
396244
6-12



FIG. 6.12
DIAGRAM, WIRING
SLAVE CONTROL TERMINAL



FIG. 6.12
DIAGRAM, WIRING
SLAVE CONTROL TERMINAL



FIG. 6.13
AUDIO BOARD
SLAVE CONTROL TERMINAL

REF.
816738



FIG. 6.13
AUDIO BOARD
SLAVE CONTROL TERMINAL



FIG. 6.14
SCHEMATIC
AUDIO BOARD
SLAVE CONTROL TERMINAL

REF.
396242



FIG. 6.14
SCHEMATIC
AUDIO BOARD
SLAVE CONTROL TERMINAL

REF.
396242